

- between pipes to attach equipment.
- 4. Refer to U16 for proper identification and marking.
- 5. In order for the meter to be accessible for operation and maintenance, a minimum of 4 feet clearance from all obstructions must be maintained in front of the meter.

METER INSTALLATION

FOR SELF-CONTAINED SINGLE OR THREE PHASE METER 240/120, 240Δ/120, OR 208Y/120 VOLTS **400-AMPERES MAXIMUM**