

*Refusal to attach service to inadequate structure is determined by OG&E installer based on but not limited to pole size and type, bracing, and attachment height.

ITEM NO.	DESCRIPTION	FURNISHED BY		INSTALLED BY	
		O.G.& E.	CONSUMER	O.G.& E.	CONSUMER
1	METER BASE	Х			Х
2	METER	Х		Х	
3	SERVICE EQUIPMENT		Х		Х
4	*SERVICE DROP	Х		Х	
5	SERVICE DROP BRACKET	Х			Х
6	SERVICE RACEWAY		Х		Х
7	SERVICE ENTRANCE CONDUCTOR		Х		Х
8	CONSTRUCTION POLE		Х		Х
9	GROUNDING ELECTRODE CONDUCTOR		Х		Х
10	GROUNDING ELECTRODE		Х		Х
11	POLE BRACES		Х		Х

TEMPORARY SERVICE 3 WIRE SINGLE-PHASE 240/120-VOLTS

APPROVED

NOTE: