

ITEM Number	DESCRIPTION	FURNISHED BY		INSTALLED BY	
		O.G.&E.	CONSUMER	O.G.&E.	CONSUMER
1	Transformer	Х		Х	
2	CT Meter Base	Х			Х
3	3-inch Galvanized Rigid pipe set in concrete		х		Х
4	Metering Conduit 1-inch sch 40 or rigid		Х		Х
5	Meter	Х		Х	
6	1 5/8-inch Kindorf and Clamps		Х		Х

Notes

to be concreted into ground at a minimum depth of 30-inches with a minimum of 6-inches of

concrete surrounding pipe.

- 1. Wiring from CTs to meter is not to exceed 20 feet in total length.
- 2. Place cap on top of pipe to keep moisture from inside of pipe to prevent deterioration.

Maximum

see note 1

- 3. Pipe to be galvanized rigid 3-inch pipe. Pipe to be set at a minimum depth of 30-inches with a minimum of 6-inches of concrete surrounding pipe.
- 3. In order for the meter to be accessible for operation and maintenance, a minimum of 4 feet clearance from all obstructions must be maintained in front of the meter.
- 4. Refer to U16 for proper identification and marking.

CT METERING COMPONENTS INSTALLATION INSTRUCTIONS ONE CUSTOMER AND CT'S IN TRANSFORMER THREE-PHASE ONLY

The following is a suggested configuration for meter bases for overhead and underground meters in residential and commercial applications. OG&E Energy Corp., its subsidiaries and affiliates disclaim any liability for the